



luxury  
flush  
door

home elevators by  
 savaria®

## The Ideal Code-Compliant Swing Door Solution

Adding a landing door for your Savaria home elevator is now easier than ever with this high quality solid, flush door. The Savaria Luxury Flush Door eliminates the potential for safety hazards between the door and the elevator cab gate and meets A.17.1 code.

With handy tuck-in channels, the aluminum frame provides seamless edges with drywall. The safety interlock device is completely concealed, as are the hidden hinges, creating a clean look. A safety release for the interior side makes for easy opening in case of emergency. The call station can optionally be incorporated into the door frame for a modern appearance. The Savaria Luxury Flush Door delivers a safe and beautiful landing door for the Savaria Eclipse, Infinity and Zenith home elevators.

## Luxury Flush Door Features

- 1 Solid slab\* 1.75" (44 mm) thickness with stability strength, paint grade finish
- 2 Option to add hall station to the frame
- 3 Add your own exterior hardware to match home
- 4 Integrated pocket in frame accommodates 1/2" drywall for seamless edges
- 5 Concealed hinges for a clean look
- 6 Low profile, white painted aluminum frame, can be custom painted on site
- 7 Completely concealed electric Kronenberg interlock, exclusive for North America
- 8 Sleek interior door hardware provides pull-to-open with emergency release mechanism



All Savaria home elevators in North America require a cab gate. See our web site for information about accordion gates, bifold doors or auto slim cab gates.

Locate a Savaria home elevator dealer near you  
1-855-Savaria (728.2742)

### AVAILABLE DOOR SIZES (opening from inside)

Minimum clear opening 34.25"

36" x 80" (914.4 mm x 2032 mm)

36" x 84" (914.4 mm x 2133.6 mm)

36" x 96" (914.4 mm x 2438.4 mm)

**Standard:** ANSI/WDMA I.S. 1A – 2013 ; CAN/CSA 0132.2 Series-90(R1998) AWI/AWMAC WI 2nd Edition (2014)

\*core is medium density particle board 28-32 lb/ft<sup>3</sup>