



Suitable for virtually any architectural requirements including public spaces and home use

Ideal for indoor or outdoor applications from basic installations to large-scale, complex projects

Finish options including frameless glass for the ultimate in luxury for upscale commercial applications

Savaria® V-1504 Vertical Platform Lift

VERSATILITY FOR ANY APPLICATION



The Savaria V-1504 vertical platform lift is built to carry a wheelchair and passenger safely up and down one or more levels.

Suitable for installations in public and commercial buildings, as well as private homes, this Savaria lift features an extremely versatile design that can be configured and customized to suit virtually any project requirements and aesthetic needs. From the rugged outdoors, to the most luxurious office tower lobbies, the Savaria V-1504 lift is ready to serve with its reliable performance, ease of use and range of finish options.



SAVARIA® V-1504 VERTICAL PLATFORM LIFT

The Savaria V-1504 vertical platform lift is available in a range of base models, all with options and configurations for customization to your needs. Please consult your local skilled Savaria dealer for complete details and local requirements for installation compliance.

STANDARD (V-1504 STD)

Ideal for basic commercial applications and home use, this lift can be used indoors and outdoors to travel a standard 48" with 2 stops or optionally more distance and stops. The standard unit can be custom enclosed on site by your local installer, or built inside a hoistway.

Order the V-1504 in standard beige powder-coated finish, or choose an optional custom color. Popular for use in schools, places of worship and other public spaces, the standard model can be outfitted with a range of options to suit the installation need.

Every Savaria V-1504 model is driven by our reliable hydraulic system and can be configured specifically for your needs. The lift travels up and down a rail system enclosed in the lift tower. The tower is supported with attachment to an existing wall or through a constructed hoistway. Because the drive system is contained within the lift tower, no additional machine room is required for installation.



Installation notes:

- 1 Custom brown paint, gate with glass inserts (photo courtesy of Transitions Mobility & Elevator)
- 2 Hoistway application
- 3 Unenclosed outdoor residential (photo courtesy of Elevators of Texas)
- 4 Tall enclosure with acrylic inserts (photo courtesy of Florida Lifts)
- 5 Enclosure with aluminum inserts (photo courtesy of Access Lifts & Service)
- 6 Prestige frameless glass with custom red tower

SMOOTH HYDRAULIC 2:1 CHAIN DRIVE SYSTEM

The lift provides a high efficiency, reliable and comfortable ride.

LARGE PLATFORM FOR EASY ACCESS

The standard platform is 36" by 54" (ADA compliant), and custom platform sizes are also available. The non-skid surface provides added safety.

FLEXIBLE DESIGN

Configure up to 23' of travel distance* with up to four stops, with a full range of entrance and exit configurations available.

EXTENSIVE FINISH OPTIONS

Choose standard beige powder coat, select from the optional color finishes, or even request your own custom color. Enclose your lift with acrylic or glass panels.



ALUMINUM/ACRYLIC MODEL (V-1504 ALPE)

This enclosed model uses aluminum and acrylic inserts and top dome with corrosion-resistant steel components, making it ideal for outdoor applications. Optionally, this model can be ordered with tempered* or laminated glass panels. The active ventilation system keeps the inside comfortable and the gates and door can be motorized.

LUXURY FRAMED (V-1504 LUX)

Framed in 316 stainless steel finish No. 4, with tempered or laminated glass inserts, this lift is a beautiful complement for lobby areas, offices and public buildings.

PRESTIGE FRAMELESS (V-1504 PRESTIGE)

With half-inch structural tempered or tempered laminated glass and no visible frame, this lift is the ultimate statement for creating barrier-free access in commercial applications.

EMERGENCY BACK-UP SYSTEMS

In addition to a manual lowering system, the lift features a DC battery powered lowering system for use in the event of a power failure. Optionally, a battery back-up operating system can be added to allow full functionality of the lift for emergencies.

EASY OPERATION

On-board controls operate the lift easily with constant pressure. Optional call/send stations can be added with or without key

access. Add an optional joystick, 60 mm buttons, or additional operating panel to add even more flexibility for user needs.

MACHINE ROOMLESS

The Savaria V-1504 does not require a machine room to house the drive component, simplifying the installation process. Alternatively, the drive system can be located in a remote machine room for ultra-quiet operation.

* consult your authorized Savaria dealer for complete specifications applicable to your local code requirements

Savaria® V-1504 Vertical Platform Lift

VERSATILITY FOR ANY APPLICATION

OPTIONS

Platform gate, top landing gate, upper/lower landing door, emergency light and alarm, motorized door, frame-mounted, wall-mounted, recessed or free-standing call stations, public building package, outdoor package, battery back-up system for up/down operation, fire-rated doors, wooden door, automatic swing door operator, doors with glass or acrylic inserts, interlock, weather resistant lock, telephone, ADA-hands free phone, folding seat, automatic safety ramp, fixed access ramp, Savaria Link wifi diagnostics and more.

SPECIFICATIONS

Applications	Residential (indoor/outdoor), Commercial (indoor/outdoor), consult local dealer for details
Capacity	750 lb (340 kg)
Maximum travel distance	23' (7 m), 12' to 14' (3.65 to 4.26 m) in some jurisdictions
Platform sizes	36" x 54" (914 mm x 1371 mm) ADA-compliant, (customize up to 17.5 sq.ft./1.63 sq. m)
Nominal speed	20 ft/min (0.1 m/s)
Levels/stops	2 to 4 stops
Car access/configurations	Enter/exit same side, 90 degree exit, straight through enter/exit
Power supply	110 volt, 20 amp, single phase, 60 Hz
Drive system	2:1 roller chain, hydraulic
Motor pump	3 hp, gear-type
Controller	Relay logic
Emergency operation	Battery-operated lowering with automatic recharging system, plus remote access manual lowering valve optional battery backup
Rail construction	8' modular guide rail assembly with roller guide shoes
Side guards	42 1/8" (1070 mm), 80" (2032 mm) optional
Finish	Powder coated steel beige, optional and custom colors available
Warranty	36 months parts, ask for details

For drawings, detailed specifications and a complete list of options for your Savaria V-1504 vertical platform lift, consult your local authorized Savaria dealer. To locate a dealer near you, visit savaria.com, or call us.

Talk to a Savaria dealer about how the V-1504 vertical platform lift can give you the access you need.



Authorized Savaria dealer:

 **savaria.**

savaria.com

2 Walker Drive Brampton ON L6T 5E1 Canada

tel: 800.661.5112 fax: 905.791.2222